

Hardware Model	Software Configuration	Description
MicroEdge Basic	VPN	MicroEdge Basic - Modular Edge Gateway + Corvina VPN LifeTime Activation Key
	JMX	MicroEdge Basic - Modular Edge Gateway + JMobile Runtime License
	IOT	MicroEdge Basic - Modular Edge Gateway + JMobile Runtime License + Corvina VPN LifeTime Activation Key
MicroEdge Plus	JMX	MicroEdge Plus - Advanced Modular Edge Gateway + JMobile Runtime License
	IOT	MicroEdge Plus - Advanced Modular Edge Gateway + JMobile Runtime License + Corvina VPN LifeTime Activation Key